


COOLEGE™

COOLEGE TILE EXTERIOR QUICK START GUIDE



For detailed instructions, please refer to EXT-0054 TILE Exterior User Guide



EN 60598 Compliant



RoHS

IP65





5 Year Limited Warranty:
Parts and workmanship

Cooledge Lighting Inc.
110-13551 Commerce Parkway
Richmond, BC V6V 2L1 Canada



O +1 604 273 2665
F +1 604 273 2660
T +1 844 455 4448
W cooledgelighting.com

Cooledge Lighting reserves the right to change materials or modify the design of its product without notification as part of the company's continuing product improvement program.



1





2





3





4



5





6





7



Cap all unused connectors





8



9



Risk of shock. Installation by a certified electrician.
See the Cooled Power & Control 24V Install Guide



AC

